



KEMEL AIR SEAL

Type KEMEL AX

(With Air Relay)

INSTRUCTION MANUAL

This manual is produced based on a typical lubrication diagram for stern tube system installed with Type KEMEL AX seals. For correct understanding and operation of the ship's system, read this booklet together with seal drawing and the piping diagram available in the finished plan. Besides this booklet, read Instruction Manual for KEMEL COMPACT SEAL Type KEMEL CX, DX & AX included in the finished plan.

EKK EAGLE INDUSTRY CO., LTD.

Marine Division

<http://www.kemel.com>


Contents

1. Outline	-----	P. 2
1.1 Construction		
1.2 Air Control Unit (MU)		
1.3 AFT Seal		
1.4 S/T L. O. Tank Unit (TU)		
1.5 Oil Pressure Unit (OU)		
1.6 Drain Collection Unit (CU)		
2. Oil Filling & Oil Pressure Test	-----	P. 5
3. Operation of Air Seal	-----	P. 5
3.1 Start-up Air Control Unit (MU)		
3.2 Operation of Air Seal		
4. Daily Maintenance	-----	P. 8
4.1 Stern Tube System		
4.2 Air Control Unit & Drain Collection Unit		
5. Trouble Shooting	-----	P. 10
5.1 Abnormalities of Air Pressures/Air Flow & Actions		
5.2 Alarms & Actions		
5.3 Other abnormalities & Actions		
6. Switch-over to normal Oil Seal System for emergency	-----	P. 13
7. Operation for Dry-docking, Undocking and Laying-up	-----	P. 14
7.1 Dry docking & Undocking		
7.2 Laying-up		

1. OUTLINE

1.1 Construction

Air Seal keeps seawater out by blowing air into sea through an air chamber (**Air Chamber**) provided at the space between the #2 & 3 seal rings in AFT seal, and it keeps oil tight by controlling stern tube oil pressure to follow change of ship's draft. Segregation of seawater and stern tube oil by **Air Chamber** minimize the risk of seawater contamination. Besides, a drain line provided at the bottom of **Air Chamber** collects and recovers leaking oil and water in engine room in case of leakage. At the same time, the system automatically optimizes the oil pressure based on draft pressure detected at **Air Chamber** and remarkably reduces the pressure load given on AFT seal at all draft levels. The construction of Type DX seal with a stand-by spare seal ring is employed on AFT seal, which enables switching-over to the spare at any time by simple valve operation. FWD seal has a same construction as existing models. The schematic diagram and the components for the system are shown in the sketch below.




1.2 AIR CONTROL UNIT (MU)



Air Control Unit (MU) regulates supplied compressed air at the pressure*) set by Air Regulator (R1) and at the flow rate*) set by Air Flow Controller (FC1) after passing Air Filters (F1 & F2). Then the regulated air lead to Air Chamber in AFT seal is blown into sea, called Air Blow Line which has a branch line to Air Relay (AR1) to give the pressure of air blowing as an input signal. Another branch line taken after Air Filters is lead to S/T L. O. Tank Unit (TU) through AR1 to pressurize it, called TU Line. AR1 regulates the pressure in TU Line at the level of the signal pressure from air blowing. AR1 has a hand wheel for fine adjustment of the regulating pressure. TU Line has change lever C2 to bypass AR1, through SUB Line, which gives TU a direct pressure from Air Blow Line. MU has a spare Air Regulator (R2) and a spare Air Flow Controller (FC2) on SUB LINE for switching over from R1 & FC1 on MAIN LINE by C1 Lever. Also MU has Fresh Water Line for periodical cleaning of air purging pipe and has an Alarm Switch for Air Pressure Low. Air Regulators R1 and R2 have pressure gauges P2 and P3 for setting air pressure. Dirtiness of Air Filters (F1 & F2) is examined by visual and Differential Pressure Gauge (DP). The gauge P1 indicates air source pressure and the gauge P4 indicates Air Blow Line pressure.

*) Set values of Air Regulators and Air Flow Controllers are shown in "Finished Plan – Piping Diagram Fig. 1".

Piping Diagram in MU



The diagram shows Air Seal operation using MAIN LINE.




1.3 AFT Seal

Air supplied from **MU** to **AFT Seal** blows out underwater through **Air Chamber**, with the pressure set by **Air Regulator**. The effects of air blow are explained below;

- 1) When the pressure in **Air Chamber** slightly exceeds the **tension forces from the #1 & #2 seal rings + seawater pressure from the draft**, the air lifts up the #1 & #2 seal lips and starts blowing into sea through the gap, formed by the lift, with the constant rate set by **Air Flow Controller**.
- 2) The gap by constant air blow makes **Air Chamber** being kept opened in-water all the time.
- 3) By this, **Air Chamber** pressure (= **Air Blow Line pressure P4**) is equalized to the level of **tension forces from the #1 & #2 seal rings + seawater pressure from the draft** or slightly above.


Because of the opening underwater, **Air Chamber** pressure does not go higher up to the pressure set by **Air Regulator**, and also continual air blowing prevents seawater penetration into **Air Chamber**. **Air Flow Controller** keeps constant flow and maintains the gaps under all draft level of the ship. Therefore the pressure in **Air Chamber** follows water pressure from draft change with no time-delay. In addition, air from **MU** partly returning to **Drain Collection Unit (CU)** with slight ventilation in E/R generates low speed air flow to remove leaking oil or water from **Air Chamber**, through a drain hole provided at the bottom lead into **CU**.




The #3 & #3S seal rings can be switched over by valve operation in E/R. (Valve "C" & "D" shown in the piping diagram P. 6.) Open these valves for the #3 in use and close them for the #3S in use.

1.4 S/T L. O. Tank Unit (TU)

TU is an air-tight oil tank having **100 - 200L** capacity and is installed to give **oil head pressure** in stern tube with **2 - 2.5M** of the oil height above shaft centerline. In addition, **TU** is connected with an air pipe via **AR1** equalizing the line pressure at **Air Chamber Pressure**. By the arrangement, stern tube is pressurized at the level of **oil head pressure + Air Chamber Pressure** which is loaded onto the #3 seal ring, supported at the same time by **Air Chamber Pressure** from seawater side while air blows out as described in Article 1.3. Because of **Air Chamber Pressure** at the front face and the back of the #3 seal ring, it counteracts each other cancelling the force. As a result, the actual load remains on the #3 seal ring is **oil head pressure** of **TU** constant at all draft. Same effect is available on the #3S seal ring when it is in use. **TU** is provided with **Safety Relief Valve** to avoid excessive pressure, and **Alarm Switches** for Oil Level High & Low. **TU** is also connected with **Oil Pressure Unit** (Oil pumps) to circulate stern tube oil.



TU Front View




TU Top View

1.5 Oil Pressure Unit (OU – Oil Pump)

OU circulates lubrication oil via “**OU → Stern Tube → TU → OU**”. Stern tube oil pressure is measured at the return line from stern tube to **TU**. The correct pressure is calculated by adding (or deduction on some cases) oil head pressure from the gauge height to the reading value. (See calculation example in [P.7](#).) Periodically examine oil suction & discharge pressures on the pumps, and clean strainers for maintenance whenever is necessary.

1.6 Drain Collection Unit (CU)

CU is an air-tight tank with 10L capacity and is located below the shaft level. **CU** is connected to a drain pipe from **Air Chamber** in AFT seal. **Flow Controller (FC)** fitted on **CU** gives air-flow at a low speed (about 5 L/min.) from **Air Chamber** towards **CU** to remove leaking seawater and oil into **CU** through the pipe. Drain recovered can be discharged by the air pressure in **CU**, through **Drain Valve**. (Discharge drain while M/E is stopped.) **CU** is fitted with **Level Gauge** and **High Level Alarm Switch**



2. Oil Filling and Oil Pressure Test

Procedures for oil filling to stern tube and oil pressure test for Air Seal is described in [P. 6](#). Confirm actual valve operation for oil filling, circulation, draining & etc. in ship's piping diagram available in finished plan.

3. Operation of Air Seal

3.1 Start-up Air Control Unit (MU)

When air supply to Air Seal become available, start-up **MU** after filling oil in stern tube by the procedures below,

- 1) Put valve positions in **MU** for blowing air as per Finished Plan – Piping Diagram Fig. 1.
- 2) Close Air Vent on **TU** and Drain Valve on **CU**.
- 3) Put valve positions for oil circulation via “**TU → OU → Stern Tube → TU**”, then start-up **OU**.
- 4) Open air source valve for **MU**.
- 5) Adjust settings for **Air Regulator R1** and **Air Flow Controller FC1** if necessary.
- 6) Confirm air blowing at AFT seal in dry-dock, or at sea surface in stern area after launching.
- 7) Record all data by using the form shown in [P. 7](#), and examine the system is working right.
- 8) Adjust stern tube oil pressure **Ps/t** by operating bypass valve on **OU** and **AR1** on **MU** if necessary.
- 9) Put **Change Lever C1** on **SUB** and examine all pressures. (FM1 does not work with **SUB** in use.)
- 10) Put **Change Lever C2** on **SUB** and examine all pressures.
- 11) Put **Change Levers C1 & C2** on **MAIN** for normal operation.

In case of launching a new ship with no air blowing, examine **CU** periodically for possible water penetration after floatation.

3.2 Operation of Air Seal

Air Seal System is in operation when blowing air into sea is started. The system automatically controls stern tube oil pressure at the optimum level responding to changes of ship's draft. Keep blowing air and operating **OU** all the time while the ship at sea as well as at berth or anchor. **OU** may be stopped for maintenance etc. while M/E is stopped. In case air source is shut off, stern tube oil pressure stays at the level of oil head pressure from **TU**. Closely watch seawater penetration in **CU** in such an event, and recover or establish air supply as soon as possible. Maintenance of stern tube system, **MU** and **CU** is done as per the article 4 in [P. 8](#).

LEAK TEST PROCEDURE in dry-dock (AIR Seal Type AX)

TYPICAL DIAGRAM - Confirm valve no.s & details in Finished Plan

Procedure Oil Filling

- 1) Fill Sump Tank, - Open Valve "1".
- 2) Close air source valve for MU, and open air vent on TU.
- 3) Close valves "C" & "D", and open valve "G".
- 4) Keep valves "A" & "H" open, and close valve "B".
- 5) Fill stern tube and TU with oil by operating OU.
- 6) Stop OU after TU filled up with half level.
- 7) Close air vent on TU.
- 8) Carry out Test Order "1" & "2", either by using:
 - a) "X"-line, or
 - b) Air pressure
- 9) Fill oil in #3/3S by Test Order "3" after "1" & "2".
- 10) Fill oil #4/5 by Test Order "6" after "3", "4" & "5".

Apply oil pressure in stern tube either by X-line or by air pressure, and carry out the test in accordance with the procedure shown in the table.


Leak test via "X"-line.

- 1) Close valves "A" & "B".
- 2) Keep valve "G" opened. Keep valves "C" & "D" closed.
- 3) Operate OU
- 4) Circulate TU \rightarrow S/T \rightarrow "X"-line \rightarrow Sump Tk for test.

Leak test by applying air pressure in MU

- 1) Close valve "G" on oil line.
- 2) Open valves "A", "B" & "H" on oil line.
- 3) Keep valves "C" & "D" closed.
- 4) Close air vent on TU.
- 5) Operate OU, and circulate oil via TU \rightarrow S/T \rightarrow TU for test.
- 6) Set valve positions in MU are for Air Blow.
- 7) Reduce Regulator setting (0.2 - 0.4MPa) on "MU" to 0.1MPa.
- 8) Close valve "E", or V4 valve in MU.
- 9) Check Ps/t shows about 0.1MPa and proceed for the test.

Switching #3 & #3S seal rings	
Valve C	Valve D in Operation
Open	#3
Close	#3S
"C"	



			Test Seal Ring Order	Procedure
1	#3S			1) Fill stern tube and TU with oil. - See left: "Procedure Oil Filling". 2) Keep valves "C" & "D" closed. 3) Apply oil pressure in stem tube. 4) Remove bottom plug between #3 & 3S seal rings on AFT seal casing. 5) Clean up seal casing/liner/oil holes to remove oil wet. 6) Leave the plug opened for more than 3 hours. 7) Confirm no oil leaking through the bottom hole. 8) Confirm no oil leaking at other area, i. e. sheet packing, "O" ring & etc.
2	#4			1) Same procedures as 1&2 for testing #3S above. 2) Remove bottom plug between #4 & 5 seal rings on FWD seal casing. 3) Clean up seal casing/liner/oil holes to remove oil wet. 4) Leave the plug opened for more than 3 hours. 5) Confirm no oil leaking through the bottom hole. 6) Confirm no oil leaking at other area, i. e. sheet packing, "O" ring & etc.
3	#3			1) Plug all oil holes/drain holes between #3 & 3S on AFT seal casing. 2) Open valves "C" & "D", to apply pressure in #3/3S chamber. 3) Close valve "H" for about 30 sec. to direct oil flows into #3/3S chamber. 4) Keep valve "H" open again for the test. 5) Remove bottom plug between #2 & 3 on AFT seal casing 6) Clean up seal casing/liner/oil holes to remove oil wet. 7) Leave the plug opened for more than 3 hours. 8) Confirm no oil leaking through the bottom hole.
4	#2			1) Leave bottom plug between #2 & 3 opened. 2) Plug bottom hole between #1 & 2. 3) Remove two plugs on top between #1 & 2, for filling and air venting. 4) Fill #4/2 chamber with "Fresh Water" through the top hole. 5) Clean up seal casing/liner/filling holes to remove wet. 6) Confirm no water leaking through the bottom hole between #2 & 3.
5	#1			1) Same procedures 1) - 5) for testing #2 seal ring above. 2) Confirm no water leaking out. 3) Drain out Fresh Water after the test. 4) Confirm all holes for filling, draining & air venting on AFT seal plugged.
6	#5			1) Plug all holes between #4 & 5 on FWD seal casing. 2) Fill #4/5 chamber with oil. 3) Clean up seal casing/liner to remove oil wet. 4) Confirm no oil leaking out. 5) Confirm all oil holes on FWD seal plugged after the test.

REMARKS

1. Carry out leak test after completion of flushing pipes.
2. Take wear-down readings before and after overhauling AFT seal, for repair ship.
3. Protect seals from sand blasting, painting, welding, chemicals, excessive heat & etc.
4. Use stainless steel fitting bolts (SUS 316 or equivalent) for AFT seal installation.
5. Secure all the fitting bolts and plugs for AFT seal by using stainless steel wire.
6. Put all valves (and regulator setting) back to "Normal Operating Condition" after the test.
7. Check P2 pressure indication for Regulator on the green mark.
8. Oil level may suddenly reduce when air-locking dissolved. Fill oil in such an event.

1. Valve positions shown above are for "Normal Operating Condition" of Air Seal System.
2. "X"-line is for oil circulation via the gravity line, not in use during operation of Air Seal System.

VV mm

1. Recording intervals: Once a day
 2. **P4, P5, Pd & Ps/t** pressures automatically follow change of water pressure from the draft.
 3. Clean filters in case of pressure rise in **DP** gauge.
 4. Clean pump strainers in case of suction pressure drop on **Oil Pressure Unit**.
 5. Put air vent pipe of FC in a water cup to check air flowing at Drain Collection Unit.
 6. Use this form in operating the system while the vessel at sea, at berth or in sea trials.

Calculation of differential pressure at shaft centerline

	Symbol	Value	Remark	Example
Gauge height above shaft C/L (m)	h		P_s/t gauge	1.5
Head pressure (MPa) P_s/t gauge *	H_p		Gauge height x 0.009	0.0135
* Fill (-) minus value in case the gauge located below shaft level.				
Check point 2.	Symbol	MPa	Remark	Example
Stern tube oil pressure	P_s/t		Variable by draft. Pd shows nearly draft pressure.	0.11 0.09
Press. in Drain Collection Unit	P_d		-	0.02
Differential Pressure $P_s/t - P_d$	ΔP		by calculation	0.0135
Head pressure P_s/t gauge *	H_p		0.03-0.05 MPa range	0.0335
Differential pressure compensated	$\Delta P + H_p$			

Initial Setting

Symbol	Standard setting	
DP	Green range (less than 0.1 MPa)	
FM1	40 or 50 L/min.	****
P1	More than 0.4 MPa	
P2	0.25 – 0.35 MPa on MAIN, 0 MPa on SUB	****
P3	0 MPa on MAIN, 0.25 – 0.35 MPa on SUB	****
		**** Adjust settings shown in Finished Plan – Piping Diagram Fig
		Height of shaft centerline above keel (m)





4. Daily Maintenance

4.1 Stern Tube System

Record and monitor operation of Air Seal as per the form in P. 7. Also monitor stern tube system as per **Operating Guideline** shown in **KEMEL COMPACT Seal Type CX, DX & AX INSTRUCTION MANUAL**. In case of questions on the data or operating condition, send the record to Technical Service Dept. at “techservice@kemel.com” for examination and comments.

4.2 Air Control Unit & Drain Collection Unit

Table below shows maintenance of **MU** and on **CU**. Also refer to photo manual in P. 9.

Unit	Devices	Symbol	Standard setting	Maintenance
MU	Air Source	—	0.4MPa Min.	Fully open air source valve and keep the pressure above 0.4MPa all the time.
	Differential Pressure Gauge	DP	Less than 0.1MPa in green zone	In red zone → Clean or renew filters. <ul style="list-style-type: none"> ① Open V10 and close V1 & V2 in MU. ② Open V3 to release air in the line. ③ Remove filter covers. (Secure O-ring fitted) ④ Remove filters. ⑤ Clean & re-set filters, or renew filters. ⑥ Close V3. Open V1 & V2, then close V10. 
	Air Filter	F1 F2		
	Air Regulator	R1/P2 & R2/P3	Set Value See Note *) Allowance ±0.05MPa	Pressure setting (Set value is shown in Finish Plan – Piping Diagram Fig.1) <ul style="list-style-type: none"> ① Pull-down the knob to unlock. ② Turn the knob for pressure setting. ③ Push-up the knob to lock. Check positions of Green Markers in P2 & P3 gauges for indication of the set value. Note: Initial setting is made for R1 & R2 at the time of delivery. 
	Air Flow Controller	FC1 & FC2	Set Value See Note *) Allowance ±5L/min.	Flow setting (the value shown in Finished Plan-Piping Diagram Fig.1.) <ul style="list-style-type: none"> ① Pull-up the knob to unlock. ② Check air flow rate at FM1. ③ Turn the knob for flow setting. ④ Push-down the knob to lock. Note: Initial setting is made for FC1 & FC2 at the time of delivery. 
	Air Flow Meter	FM1		
	Air Relay	AR1	"Ps/t -Pd" value in the range 0.03 -0.05 MPa	Adjust Ps/t (See P.7 Calculation of differential pressure) <ul style="list-style-type: none"> ① Loosen lock-nut for control wheel ② Turn clockwise to increase, conuter clockwise to decrease ③ Adjust stern tube pressure ④ Tighten the lock-nut 
	Change Lever	C1	on MAIN	<ul style="list-style-type: none"> ① On MAIN: Air blows into sea via R1→P2→FC1→FM1. ② On SUB: Air blows into sea via R2→P3→FC2, bypassing FM1. ③ SUB is only for temporally use. (FM1 does not work.) ④ Recover MAIN to replace SUB as soon as possible.
	Change Lever	C2	on MAIN	<ul style="list-style-type: none"> ① Main; AR1 controls air pressure in TU line by using Air Blow Line pressure as a signal. ② Sub; bypass AR1 and pressurize TU line by direct pressure of Air Blow Line. ③ SUB is only for temporally use. ④ Recover MAIN to replace SUB as soon as possible.
	Air Flow Controller	FC	Slight Open	<ul style="list-style-type: none"> ① Check ventilation through the vent, with low air-speed. ② Turn the knob to adjust flow speed after the lock nut loose, if necessary. ③ Tighten the lock nut after setting air flow. Note: Initial setting is made for FC at the time of delivery. Put air-vent pipe in a water cup to check ventilation bubbles.
	Level Gauge	—	—	<ul style="list-style-type: none"> ① Remove drain in case of high level alarm activated. ② Slight-open drain valve for discharge by air pressure in CU. ③ Discharge while M/E stopped. (Do not open the valve when M/E in operation.)

Note *) Adjust settings shown in Finished Plan – Piping Diagram Fig. 1.

OPERATION of AIR CONTROL UNIT and DRAIN COLLECTION UNIT




Photo 1. Air Control Unit (MU)




Photo 2. Air Flow Controller FC1 (Side View - Left)





Photo 3. Air Regulator & Air Filters



P2 & R1: Air Regulator Main (Lower)
P3 & R2: Air Regulator Sub (Upper)
(Pull down the knob and turn, to set the pressure on the green mark.)

Photo 4. Removal Filter Elements




Photo 5. Drain Collection Unit (CU)




Photo 6. Air Flow Controller FC2 on SUB (Side View - Right)

NOTE: Do not open filters before isolating them from air pressure line!

Procedure for isolating filters
① Open V10 to keep bypassing airline.

② Close V1 & V2 for isolation.

③ Open V3 for air release.

④ Open filters.

Procedure for re-activating filters

① Install filters.

② Close V3.

③ Open V1 & V2.

④ Close V10.

- 1. FC2 works with change lever C1 on SUB.
- 2. The initial setting is made at 40 or 50L/min.
- 3. Change flow rate as same manner as FC1.
- 4. Flow meter FM1 does not work with FC2.
- 5. SUB is used only for temporarily operation.
- 6. Recover MAIN at the earliest opportunity

FC2.
Air Flow Controller

5. Trouble Shooting

5.1 Abnormalities of Air Pressures/Air Flow & Actions

Unit	Gauge	Abnormality	Possible Cause	Action
	P1	Low, or "Zero" pressure. (Minimum 0.4MPa required.)	Air source valve closed. Air source pressure low. P1 gauge malfunction.	Open air source valve. Keep the pressure above 0.4MPa. Replace P1 gauge.
	P2	Low, or "Zero" pressure.	Change Lever C1 is on SUB . Air Regulator R1 setting changed. P2 gauge malfunction. Air regulator R1 malfunction.	Put C1 on MAIN , if it works. Re-adjust R1 setting. Replace P2 gauge Put C1 on SUB . Replace R1 .
	P3	Low, or "Zero" pressure.	Change Lever C1 is on MAIN . Air Regulator R2 setting changed. P3 gauge malfunction. Air regulator R2 malfunction.	No action required. Keep C1 on MAIN . Re-adjust R2 setting. Replace P3 gaugeReplace R2 .
MU	P4	Rises up to R1 (or R2) set pressure. Gets higher pressure in the same draft level before. Low, or "Zero" pressure. The pressure does not follow change of draft.	Valves on Air Blow Line are closed. 3-way valve on Air Blow Line in direction F/N cleaning. Blockade proceeding in Air Blow Line. Air leakage from air pipes P4 gauge malfunction	Open the valves. Put 3-way valve in direction of air blowing. Clean pipe by using fresh water line in MU , while M/E stopped. Check pipes by spraying soap water, and repair. Replace P4 gauge.
	P5	Considerably lower than P4 pressure. Considerably higher than P4 pressure.	Pressure gauge malfunction. Wrong setting AR1 . Air leakage on TU line Malfunction AR1 . Pressure gauge malfunction Wrong setting AR1 . Malfunction AR1 .	Replace pressure gauges. Re-adjust AR1 . Check pipes by spraying soap water, and repair. Put C2 on SUB . Replace AR1 . Replace pressure gauges. Re-adjust AR1 . Put C2 on SUB . Replace AR1 . Clean or replace filters.
	DP	Indicator needle in "Red Zone".	Dirty filters F1 & F2 . Air Flow Controller FC1 setting changed. Air Flow Controller FC1 malfunction. Air Flow Meter FM1 malfunction.	Re-adjust FC1 setting. Put C1 on SUB . Replace FC1 . Put C1 on SUB . Replace FM1 .
	FM1	Out of setting range.	Drain valve or Air Flow Controller FC fully opened. Blockage or air leakage at drain pipe lead to CU Pd gauge malfunction	Close drain valve or re-adjust FC slight open. Clean pipe by fresh water line in MU , repair pipe. Replace Pd gauge
	CU	Pressure low. Pressure does not follow change of draft. Filled with seawater. Gauge Filled with oil.	Seawater leakage through the #1 & 2 seal rings. Oil leakage through the #3 seal ring. Air vent valve on TU is opened. Air leakage at the pipe lead to TU or TU itself.	Remove water. Record daily amount and report. Remove oil. Record daily amount and report. Close air vent valve. Check pipes by spraying soap water, and repair. Replace Pst/t gauge
TU · OU	Ps/t	" Ps/t – Pd " value is greater than 0.05 MPa, with compensation of Ps/t gauge height.	Valve "A" on return line to TU is not fully opened. Bypass valve on OU is fully closed. Tu Line pressure too high.	Fully open valve "A", shown in P. 2 diagram. Re-adjust the bypass valve. Adjust TU line pressure by AR1 hand wheel.

5.2 Alarms & Actions


ALARM	Unit	Check Point	Abnormal Condition	Possible Cause	Action	Report to KEMEL
		DP Gauge	The indicator in Red Zone, exceeding 0.1MPa.	Dirty filters. R1 setting changed. Malfunction R1. Malfunction P2.	Clean or replace filter elements. Re-adjust R1 setting. Put C1 on SUB. Replace R1. Replace P2.	
MU		P2 Gauge	P2 indicates below the minimum set pressure. (see Finished Plan – Piping Diagram Fig. 1)			
A1 (MU) Air pressure Low	TU	FM1 Flow Meter Valve positions	Flow rate is below the minimum value. (see Finished Plan – Piping Diagram Fig. 1) Wrong position. (see Finished Plan – Piping Diagram Fig. 1)	FM1 setting changed Malfunction FM1. –	Re-adjust FC1 setting. Put C1 on SUB. Replace FC1. Correct valve positions.	
CU	Air pipe joints Air vent	Safety relief valve Air pipe joints Air vent	The relief valve activates at lower pressure. Air leakage. (Check by spraying liquid soap.) Air vent valve opened.	Malfunction valve. Loose joints etc. –	Repair/Replace the relief valve. Repair leaking joints/pipes. Close the valve.	
CU	Flow Controller FC Air pipe joints Drain Valve		Excessive air flow at FC. Air leakage. (Check by spraying liquid soap.) Drain valve left opened.	Setting changed. Loose joints etc. –	Re-adjust FC with 2-3 air bubbles/sec. Repair leaking joints/pipes. Close drain valve.	
Air Source			Loss of air source pressure.	–	Take actions in P. 13. Recovery of air	
A2 (TU) Oil Level High	OU	Pressure gauge Strainer Oil color	Negative pressure at pump suction, causes air sucking. Dirty strainer. Air bubbles (Increased oil volume by air inclusion.)	Dirty strainer Particles in S/T oil Air inclusion	Clean strainers.	
FWD seal	TU	Level gauge Stern tube drain CU Level gauge	Level increase in shallow draft and decrease in deep draft Sign of seawater penetration. Filled with seawater immediately after draining.	Air-pocket in S/T. AFT seal damage	Dissolve air-pocket. Increase air flow rate at 60 – 80L/min. Conduct diver inspection. Repair AFT seal.	Yes
A2 (TU) Oil Level Low	FWD seal	Level gauge	Decrease oil level in FWD seal tank, and increase the level in TU with same amount. (Pumping effect.)	Pressure fluctuation in S/T.	Increase S/T oil pressure. *** Re-fill oil in FWD seal, whenever is necessary.	Yes
A3 (CU) Liquid Level High	TU	Oil pipe joint Level gauge FWD seal	Oil leakage Oil level increases over 2L/day. Oil level increases over 2L/day.	Loose joint Leakage from the #3 seal ring Leakage from the #4 seal ring	Repair pipe joints. Activate the #3S seal ring. Recovery. Repair the #4 seal ring	Yes
	CU	Level Gauge Drain	Continuous seawater recovery. Filled with seawater in a day. Recovery of oil over 2L/day	Damage of the #1 & 2 seal rings Damage of the #3 seal ring	Increase air flow rate at 60 – 80L/min. Conduct diver inspection. Repair AFT seal.	Yes
				Damage of the #3 seal ring	Activate the #3S seal ring.	Yes

*** Increase oil pressure by operating Air Realy "AR1" on MU.

The differential pressure " $P_s/t - P_d$ " should not exceed 0.05MPa. (See P. 7 Calculation of pressures)

5.3 Other abnormalities & Actions

Abnormalities	Check Point	Possible Cause	Actions	Report to KEMEL
Seawater penetration into stern tube with no seawater collected in CU.	Air pressure in CU. Stern tube oil condition.	Blockade in drain pipe.	Increase air flow rate at 60–80L/min. Clean pipe by using Fresh Water Line in MU. Conduct diver inspection, if necessary.	Yes
Stern tube oil leak with no collection of oil in CU.	Pressure in CU. Oil level in TU.	Broken pipe in stern tube Blockage in drain pipe.	Activate the #3S seal ring and keep monitoring. Cleaning Air pipe by Fresh Water.	Yes
Air pressure high alarm (Option) from A1.	Valve position on Air Blow Line. P4 pressure on MU.	Valves remain closed. Blockade in Air Blow Line.	Open the valves. Clean pipe by using Fresh Water Line in MU.	Yes



Cleaning Air Pipe by Fresh Water

In case P4 pressure become higher than Pd over 0.03MPa difference, it is possible that air flow pipes started to have blockage due to extraction of salt etc. MU has a freshwater line to dissolve the blockage and to clean the pipe. It is recommended that the ship clean the pipe by using the line with 6months intervals.

Procedure for Fresh Water Cleaning (To be done while M/E stopped or on turning gear.)

- 1) Open drain valve on CU.
- 2) Turn 3-Way Valve in MU, to the direction of Fresh Water Line. - Note 1
- 3) Open the valve and start supply fresh water.
- 4) Clean the air pipe till fresh water coming out from the drain valve on CU. - Note 2
- 5) Stop fresh water supply.
- 6) Turn 3-Way Valve in MU, to the direction of Air Blow Line.
- 7) Close the drain valve on CU after blowing out water by the air.
- 8) Examine all pressures and air flow being in normal condition.

- Note1. When 3-way Valve is turned to the direction of Fresh Water, Air Blow line is shut off and air pressure set by R1 is directly given to TU. This may cause activation of Safety Relief Valve on TU, which is not harmful. The activation of Safety Relief Valve may be stopped by reducing R1 setting during Fresh Water Cleaning. However, do not reduce R1 setting in case of continual seawater leakage into CU. Also make sure R1 should be back to the set value after the cleaning.
- Note2. It takes a time to have cleaning water coming out at CU drain. (Flow Control Valve on fresh water line is initially set and locked at very slow speed so that the water does not penetrate into stern tube by sudden rise of water pressure. In case the initial setting is lost, fully close the control valve then turn the wheel 180 degree, half-turn, for re-setting.

6. Switch-over to Oil Seal System for emergency

Losing air supply to AFT seal causes oil pressure drop in stern tube. In case of air lost while the vessel is at sea, immediately examine seawater penetration in **CU**. It is possible to operate the system without air if no seawater is observed in **CU**. Air supply, however, should be recovered to raise the oil pressure at the earliest possible. During the operation with no air, keep monitoring **CU** by frequent examination of the drain. In case no air supply to **MU** may continue for a long period, study possibilities of slow-down or stop M/E till air supply is recovered.

If seawater continuously fills **CU** in a short time, conduct protection of stern tube bearing from seawater by switching Air Seal system over to normal oil seal system as per the procedures below,

- 1) Switch-off all alarms on **MU**, **TU** and **CU** and stop air supply.
- 2) Stop **OU**, and then take action 3) with no delay.
- 3) Change oil circulation I via **X-line** as per "Valve Operation for switching to **X-line**" shown below
- 4) Re-start **OU** with no delay.

While operation with **X-line**, keep **OU** running all the time to maintain the oil head pressure which minimizes the chance of seawater penetration into stern tube. Strengthen examination of stern tube oil drain and remove contaminated oil when it is found. It is necessary to recover air source failure as soon as possible. At the same time, investigate possibility of earlier inspection and repair of AFT seal for seawater leakage.

Valve Operation for switching to **X-line**


	MU		CU		TU		OU		X-line
Valve	V11	E	F	A	B	Air Vent	I	G	
Operation	Close	Close	Close	Close	Close	Open	Open	Open	

Note 1. V11 valve is located in **MU**, on the line to pressurize **TU**.

Note 2. Confirm detail valve operation in Finished Plan – Piping Diagram Fig. 2.

Valve Operation for switching back to Air Seal

	X-line	OU	TU			CU	MU	
Valve	G	I	Air Vent	B	A	F	E	V11
Operation	Close	Close	Close	Open	Open	Open	Open	Open



7. Operation for Dry-docking, Undocking and Laying-up

7.1 Dry-docking & Undocking

In case of dry-docking and undocking, shut-down and re-start Air Seal system as the manners below,

- 1) Stop all alarms on **MU, TU** and **CU**, and then stop air supply to **CU** to shut-down before entering dock.
- 2) Discharge oil in stem tube, AFT seal and FWD seal for seal repair after dry-up.
- 3) Carry out inspection or repair of the seal unit as necessary.
- 4) Fill stem tube and carry out oil pressure test as necessary. (See P. 6 for oil filling and pressure test.)
- 5) Re-start the system before undocking. (See articles 2 & 3 for the procedures.)

7.2 Laying-up

In case of laying-up the ship with no power and no air, shut-down Air Seal system as the manners below,

- 1) Stop all alarms on **MU, TU** and **CU**.
- 2) Stop **OU** to shut-down the system.
- 3) Examine existence of seawater in **CU** through the drain valve.
- 4) In case of no seawater observed, carry out drain check once a week after the shut-down.
- 5) In case seawater fills **CU** in a short time, conduct protection of stem tube bearing from seawater by switching Air Seal system over to normal oil seal system using **X-line** as per article 6.
- 6) Circulate stem tube oil via **X-line** by operating **OU**.
- 7) Check oil pressure at **Ps/t** gauge.
- 8) Stop **OU** to shut-down the system.
- 9) Confirm the oil head is maintained.
- 10) Examine **Ps/t** once a week and stem tube drain.
- 11) Recover the pressure by the procedures 6) – 9), if necessary.

Re-start Air Seal after the laying-up period as the manners below,

- 1) Operate the valves as per article 6 “Valve operation for switching back to Air Seal”.
- 2) Confirm drain valve on **CU** is closed.
- 3) Operate **OU**.
- 4) Supply air to **MU** and activate all alarms on **MU, TU** and **CU** to re-start.
- 5) Examine all pressures and air flow of the system.

It is possible that marine growths around AFT seal area during laying-up period may cause reduction of seal tightness. Recommend cleaning and overhaul inspection of the seal at the earliest opportunity after re-activation of the system.